

1978 Batavus Starflite Moped Viewed from the top with cover removed When switch is moved to the "LO" position, the blue wire becomes energized and Typical "Superman" style taillight assy with common sends voltage to the headlight circuit ground to mounting stud 6V/1.2w Speedo lamp 6V/21w Head lamp HT Coil **ENGINE** Headlight/Speedo light Circuit Yellow wire out of the engine is the feed wire for the headlight, speedo light Terminal connections inside of headlight housing *Note: Brake Light works off it's own Magneto/Gen Coil and is not affected by the headlight circuit VintageMopeds.net

Horn button -

When horn button is pressed, red wire completes the ground connection which allows power

Red wire to horn












VintageMopeds.net


















6 V/ AC type buzzer horn

Feeds power to horn circuit














VintageMopeds.net